



AQUAGUARD 5000 ONE GALLON VINYL LINER STAIRS INSTRUCTIONS

- 1. Sand Stairs with an orbital sander with 60 grit paper**
- 2. Wipe stairs thoroughly with MEK or Acetone Solvent**
- 3. Tape all areas not to be painted.**
- 4. Mix 50% of Part A and 50% Part B with 6oz. Epoxy Reducer in a small container counter clockwise for 1 ½ minutes.**
- 5. Roll Apply with 9" X 3/8" epoxy roller nap. Reapply 2nd coat immediately after 1st coat dries.**
- 6. Refill Pool After 24 hours.**