

## **How to Mix AquaGuard Trowel Patch Kits**

Mix 2 Parts A (Large Container) to 1 Part B (smaller Container)

Example: Mix 8 ounces of Part A with 4 ounces of Part B.

Mix Thoroughly by using a one gallon paint stick or small mixing paddle/blade.

Once complete – pour onto a 8X8” piece of heavy cardboard. Apply with AquaGuard spreader card (included).

Sand in 6-24 hours depending on ambient temperature and geographic area.

Wipe all repaired areas with MEK prior to applying AquaGuard 5000 Top Coat.